ACARI

USER DIRECT ONE YEAR WARRANTY

ACARI Engineering Company, LLC warrants products of its manufacture against defects in material and workmanship. This is provided that the product has been installed and operated in accordance with the manufacturers' recommendations. During the warranty period, an Authorized ACARI Repair Center will repair or replace (at its option) any parts or assemblies of the unit which disclose a defect in material or workmanship. The Repair Center will return the repaired unit, transportation cost prepaid.

The above warranty is between the first purchaser (ultimate user) only and ACARI Engineering Company, LLC (manufacture). No prior authorization is required for returning ACARI products for warranty consideration. Each ACARI product sold is covered only by the official warranty in effect at time of purchase.

This warranty is not applicable to any ACARI product that has failed due to abuse, misuse, improper installation, and excessive alterations to the product that affects, in the manufacture's judgment, intended use and service. ACARI will not be held liable for any incidental or consequential damages, and assumes no responsibility or liability for expenses incurred in the removal and/or re-installation of products requiring services and/or repair; nor the packaging, handling, and shipping to the Authorized ACARI Repair Center; nor the handling of products returned from the repair center after service or repair. There are no other warranties, expressed or implied, including, but not limited to, any implied merchantability or fitness for a particular use. ACARI Engineering Company, LLC reserves the right to modify this warranty statement at any time; or discontinue, modify, or upgrade any products of its manufacture with design improvements without prior notice.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

ACARI products are covered by a direct warranty for up to a maximum one year from date of purchase (not to exceed two years from the date of manufacture), with proof of purchase. In accordance with the policy statement described herein, the unit may be returned directly to the Authorized ACARI Repair Center for warranty consideration.

STEPS TO BE TAKEN FOR WARRANTY RETURN:

- 1. ACARI products are to be returned freight prepaid to the Authorized ACARI Repair Center.
- A copy of the sales receipt must be returned with the defective unit to qualify for warranty coverage from date of purchase.
- 3. Include a short statement explaining the problem.
- 4. Include your name, address, and day-time telephone number.
- ACARI and its Authorized Repair Centers will, via UPS, ship back the repaired unit freight prepaid, usually within a few days after its receipt.

The only AUTHORIZED ACARI REPAIR CENTER(S) are predetermined by the ACARI Factory via official listing obtained form ACARI Engineering Company, LLC.

ACARITM Engineering Company, LLC

500 Main Street, Deep River, CT 06417 Phone: (860) 510-0134



ENGINEERING COMPANY, LLC

500 Main Street, Deep River, CT Phone (860) 510-0134

Sales e-mail: sales@acariproducts.com

Installation Guide:

Drill-Free Roof Top Mount

ACARI AT-GM-EV

(Formerly Talon)

for 2023-24 GM & Chevrolet

1500 EV with Spoiler Applique

Safety First!

These instructions provide all the necessary directions and information to allow your ACARI product to be safely and properly installed. Before beginning the installation of your new ACARI product, please have the installer and the operator read these directions thoroughly. Important information regarding the safe installation and safe operation of your ACARI product is contained that could prevent serious damage and injury to yourself or others.

The ACARI RTM is designed to facilitate the quick and simple installation of devises normally mounted to the roof of a pickup truck. Our product provides a durable platform onto which these devises may be mounted without requiring holes to be drilled into the cab roof for fastening or wiring access. ACARI provides a system of weather-resistant gaskets and deflectors designed to redirect wind and moisture in common applications. PLEASE NOTE: ACARI RTM is not designed to be weather-proof in the event of power washing, mechanical car washing, or other forces beyond normal highway operation.

It is the responsibility of the owner/operator to periodically inspect the RTM to be sure the platform system remains secure and the weather resistant gasketing is snug.

The ACARI RTM is designed to provide a mounting platform for lighting, antennas, GPS, and other devises. In no way is the ACARI RTM to be used as a load bearing rack for ladders or other equipment or supplies. The recommended weight restriction of the ACARI RTM is **30** lbs.

The ACARI RTM is designed to provide a mounting platform but in no way provides advice on the possible electronic effect of mounting various devises within any proximity to another. The ACARI RTM is manufactured of powder coated aluminum but is mounted to the vehicle with gaskets to provide a water-resistant bond and protect the finish of the vehicle. As such, the ACARI RTM **may not** be grounded to the vehicle without the installation technician applying an appropriate grounding mechanism.

MOUNTING THE UNIT:

The ACARI **AT-GM-EV** Drill-Free Roof Top Mount (RTM) has been designed with a focus on simplicity of design and vehicle installation. As with any new task, the first installation will require greater time and effort than those that follow. We have outlined the essential tasks required with step by step instructions. There will be variations based on the options offered with the vehicle. Our experience was 55 minutes total time on our first install with a novice upfitter. By our fifth upfit we were down to 15-20 minutes

NOTE: To maximize protection of the factory finish of the Spoiler Applique, retain the product packaging to use in the assembly process.

- Vehicle Preparation: Remove Body Side Rear Window Garnish Molding from quarter pylons on both sides of the rear interior of the cab. Per GM shop instructions, loosen cover, remove 7mm bolt, pull hook down and un-clip to remove, sliding down the safety belt assembly and out of the way.
- 2. Remove door frame trim molding along top and back edges and allow to hang in place.
- 3. Removing the headliner; find the screw cover plugs over the doorway and remove. Using an 8mm socket, remove the headliner mounting brackets above the doors and set aside. Carefully separate the rear edge of the headliner from the top of the window molding and unclip the two retainers and detach the wiring harness allowing the rear of the headliner to hang. Caution: the edge of the headliner panel and other vehicle components may be sharp. Protective gloves are recommended.
- 4. Using a 10 mm socket, remove the four mounting nuts across the width of the spoiler applique.
- 5. Using a swivel head 10 mm drive, remove the six mounting bolts, two at each corner end and middle.
- 6. With a team mate holding the spoiler applique from the exterior of the vehicle, compress the yellow bayonet clips with a pair of pliers and push through.

- 7. Remove the rubber wire harness gasket from the body of the vehicle and remove the spoiler applique to work bench.
- 8. Place the spoiler applique in an inverted position on a protective surface to prevent damage to the finish. Remove the screws holding the Chimsel lamp housing and separate.
- 9. **Platform Preparation:** Open RTM package and remove all parts. Retain product packaging!
- 10. Mount and fasten lights and other apparatuses to be installed on the platform, attaching and fastening each to their manufacturers' installation requirements. NOTE: any attachments may NOT use studs projecting greater than ½" or risk damage to spoiler applique finish. All wiring should include 24 to 30 inch leads and connectors. At same time, make up the corresponding wire harness for connection inside the vehicle. Lengths will vary.
- 11. Invert the RTM with the attachments and place inside the retained shipping box as a cradle with the "U" tabs facing toward you. Hold the Spoiler Applique in an inverted position with the front edge facing toward you. Slide leading edge of Spoiler Applique into the "U" tabs channel over the plastic boss of the center two studs. Lead apparatus wires outside of the pivot clamps of the RTM, then lower the Spoiler Applique onto the RTM and align pivot clamps with Chimsel mounting tabs.
- 12. Re-lead the Chimsel lamp wire and re-install the lamp housing in the Spoiler Applique. Confirm the apparatus wires are loose and free of pinching or abrasions.
- 13. Return the completed assembly to the roof of the vehicle and place on a work cloth to protect the factory finish, forward of the final location. Relead the Chimsel wire through the body and reinstall the factory gasket. GM provides three additional holes, each with a flexible watertight plug. NOTE: The method of running the apparatus wiring through one or more of these holes in a watertight method is the sole responsibility of the upfitter/installer.
- 14. Register the yellow bayonet clips in the appropriate holes and reinstall the Spoiler Applique onto the vehicle.
- 15. Run appropriate interior wiring for apparatus then complete steps 1-5 in reverse order to complete installation.
- 16. Install the provided adhesive back foam strip along the top edge of the Chimsel lamp housing to complete the weatherproofing.